POT compost container



Compost container green, Art. No. 4005.04 recycling, Art. No. 4005.51

H 22 cm / L 18 cm / W 18 cm Capacity 5 Litres Design Jean-Franck Haspel



Compost container with activated charcoal filter green, Art. No. 4005.14 recycling, Art. No. 4005.55

Recommended accessory:



Replacement filter Set of 2, Art. No. 4005.99

Instructions for use

Recommendations for use of the POT compost container

The POT compost container, makes it easy to collect your organic waste. Simply follow the following guidelines.

Correct insertion of POT compost container

When preparing fruit or peeling vegetables, the POT compost container can be placed directly on the kitchen worktop. Wash your compost container in the dishwater or dishwasher.

Organic waste is liquid waste

To capture the moisture, place 2 to 3 sheet of kitchen roll in the bottom of the compost container before collecting your waste. This prevents soiling and makes it easier to clean the compost container.

Organic waste is active waste

When cut off from air, organic waste quickly starts to develop an odour. For this reason, we recommend you empty the compost container regularly at your organic waste collection point.

Bags for organic waste?

If you want to use a plastic bag to protect the compost container from contamination, we strongly recommend the use of transparent, biodegradable bags. Conventional plastic bags will have to be sorted by hand from the organic waste prior to composting.



A. & J. Stöckli AG Ennetbachstasse 40 CH-8754 Netstal +41 55 645 55 75 haushalt@stockli.ch www.stockli.shop